
# Zylinc Attendant Console Quick overview






© 2018 Zylinc A/S 65 Rev. 1 EN-US

# Zylinc Attendant Console Handle calls





Agent modes

- A: The agent automatically receives calls to answer
- M: The agent must manually select the calls to answer
- **F**: The agent gets calls on another device (Follow Me mode)

# Call, answer, hold

#### Call someone

- Enter a number [1] or select a number [B].
- Click Dial [2].

## **Answer incoming call**

- Select the call that you want to answer [A]. You can only answer calls when you don't already handle a call.
- Click Answer [3].

### Put ongoing call on hold

- Click Hold [4].
- The button changes to Resume. Click it when you're ready to resume the call.
- If you call someone while you have an incoming call, the Hold button changes to Toggle.

# Transfer, camp

## **Attended transfer**

- During an incoming call, call and speak with the person who should get the incoming call. The **Hold** button changes to Toggle.
- If required, click **Toggle** [4] to toggle between your calls.
- When ready, click **Transfer** [5] to connect the two calls.

#### Unattended transfer

- During an incoming call (that isn't on hold), enter [1] or select [B] the number that you want to transfer the call to.
- Click Transfer [5].

#### Camp call (transfer call to busy phone)

- During an incoming call (that isn't on hold), select [B] the phone that, when it's no longer busy, should get the call.
- Click Camp [6].

# Park, withdraw, record

- During a call, click Park [7]. The button changes to Retrieve.
- To retrieve the call, select your parked call in Transfers [C], and click
- You can only retrieve parked calls when you don't already handle a

#### Cancel unsuccessful transfer/camp

- In Transfers [C], select the call that you want to withdraw.
- Click Withdraw [8].

## Record call (if possible in your organization)

- Click Record [9] during a call.
- Even if you click **Record** in the middle of a call, the call will be recorded from the beginning.



© 2018 Zylinc A/S 65 Rev. 1 EN-US